

Bike Configuration


The Espresso User Console is used for all bike configuration steps. Follow these instructions and the instructions on the screen to easily configure your bike.



Power on the bike

1. Connect the AC power cable to the surge protector
2. Turn on the bike using the power switch on the control panel of the bike

Configure the bike

1. Enter *CONFIGURATION Main Menu*
 - a. Select *TRY* and press **OK** (or press **OK** if not connected to the internet)
 - b. Enter Manual Mode
 - i. Press **OK** again – you will see the Route Selection menu
 - ii. Press Menu ()
 - iii. Select Manual Mode by using down arrow and press **OK**
 - c. Type 7913 – Configuration Main Menu (shown below) will be displayed



2. Configure the bike - Select **Configure Bike** and press **OK**



Follow the on screen instructions to complete the configuration steps. A brief description of the steps follows:

- a. Calibrate Steering – Follow the on-screen instruction to calibrate steering
- b. Resynchronize Time – Synchronize bike clock with Espresso.net server. Recommended.
- c. Configure Time Zone – Default is PST. Recommended
- d. Set Idle Timeout – Default is 60 seconds. Not Required.
- e. Set Player ID – Assign unique ID to each bike for multi-player function. Required for multiple bike installations only.
- f. Toggle Network Riders – Default is Network Enabled. Network needs to be enabled in order to utilize network features such as Ghosts, fitness data logging and multi-player.
- g. Toggle TV – Default is TV Disabled.
- h. Configure TV System – Set region and country for TV. Recommended if TV is enabled.
- i. Configure TV channels – Turn on/off channels. Define default channel. Recommended if TV is enabled.
- j. Configure Music – Turn on/off channels. Default is mature audience channels are off. Not Required.
- k. Enable Logins – Turn on/off rider login capability.
- l. Set Metric System – Turn on/off metric display of distance.
- m. Set Steering – Not recommended to upright bikes. It allows reversing steering move vs. direction of the bike.
- n. Station Health – Not Required. It is a diagnostics tool.
- o. Reset Location – Should be used for offline stations only. Change the location name displayed on the station.

Follow the on-screen instructions to return to **MAIN MENU**.

3. Configure Network - Select **Use Network** and press **OK**



- a. Select **Ping Espresso Server** and press **OK**. It checks network connectivity.
- b. **Upload log files**. Log files provide detailed information about the bike computer. Upload the log file after initial installation, or as requested by IFH Customer Service.
- c. Follow the on-screen instructions to return to **MAIN MENU**.

4. Exit Config Mode - Select **Exit Config Mode**